

The EM Pump User Guide



The EM Pump requires **3 high quality AAA** batteries, not included.

1. The battery panel slides out from the back. The best way to remove the cover is to turn the unit over, place both thumbs on the battery cover and push. It should slide out with ease. (Note the small +/- signs to install the batteries correctly.)
2. Turn the ON / OFF switch (located on the front of the unit) to the **ON** position by sliding the switch to the left of the case. Turn **OFF** by sliding the switch to the right of the case.

The Use of this item in ANY media production is strictly prohibited without prior written approval from Digital Dowsing LLC.

www.digitaldowsing.com



Digital Dowsing



Using the EM Pump



Version 2.0
Copyright © 2006-2013
All rights reserved
For Entertainment Purposes Only

Digital Dowsing LLC.
www.digitaldowsing.com

How the EM Pump Works and What It Does

When turned on, the EM Pump indicator light will turn on and flash slightly.

The EM Pump starts out by producing .2Hz ** pulse and increases to 256 Hz ** pulse.

You will notice that the LED becomes brighter as the pulse frequency increases.

The EM Pump creates a low level magnetic field, a magnetic white noise if you will. Since the frequency and duration changes, it is thought of as a beacon or trigger device.

Also it can be used as a sacrificial battery source. The GAC guys found this happens on film!

Currently the pumps are being used by Ghost Adventures, **seen on several episodes in 2009!**

** calculated frequencies based on operational rates of the on-board microprocessor.

Where to Use It

Set the device in an area where you are trying to capture EVP or photographic evidence.

Simply set the device down, turn it on and let it run. Bring an EMF meter close to the device; you will see the field change.

Don't set the EMF meter directly on the EM Pump!! The field strength that close could damage your EMF meter.

EMF emission at 4" inches from the device is very low. For safety sake, set the unit down, turn it on and stand 12" inches or more away or more.

Need Help?

E-mail us at: help@digitaldowsing.com

- State the nature of your problem.
- Please provide detailed information about the problem, including pictures or drawings if needed.

We try to respond in 24 hours or less,
Monday – Friday 10am to 5pm.

EM Pump Disclaimer

1. The EM PUMP is sold without any expectation. It is to be considered experimental.
2. The EM PUMP is sold as an **experimental device only**. We make no claim to the validity of the data received by these devices.
3. We make no claim as to Spirit communications, Aliens, Ghosts or any other type of phenomena.
4. You agree not to expose children to this device, or any person who may be harmed or damaged by exposure to this device. Further, you must be over 18 and in sound mental condition.
5. As the owner of this device you are responsible for the devices use. Further, you are responsible for the safety of others who may come in contact with this device.
6. This device should not be used by children under the age of 18. Further, this device should not be used by anyone with a history of mental illness.