


The Ovilus II User Guide



1. The Ovilus II requires **6 AAA** batteries*, not included. Carefully remove back cover and install batteries in their proper order; note the + and – of the batteries.

*We recommend using new, brand name, alkaline or lithium batteries. Do not use mismatched or “heavy duty” batteries. *Low battery will cause the display to become erratic.**

Operating the Ovilus II



1. The Mode switch, on the front of the device, will allow the user to switch between the user modes. To switch modes, hold down the Mode switch until the screen changes. This may take a few seconds depending on the mode you’re changing from.
2. The ← and → buttons are active in Word Mode, Contrast Mode, Volume Mode, Voice Mode and B-Light (BackLight) Mode. They allow the user to change setting levels.
3. To exit any mode, simply press the Mode button until the screen changes.



At the end of the Ovilus II are the Ports and the Power switch.

Sliding the Power switch up toward the face of the Ovilus II will turn it on.

PORTS

USB: The USB port is designed to upload new word list or to flash program new operating software.

AUX: Expansion port for external interface modules.

SPK: Port for external speaker.

www.digitaldowsing.com



Using the

OVILUS II



Version 1.0

Copyright © 2006-2012

All rights reserved

Experimental ITC Device

For Entertainment Purposes Only

Digital Dowsing LLC.
www.digitaldowsing.com

**Need help? Contact us at
help@digitaldowsing.com**

The Ovilus II Modes

- **Word Mode:** This is the default mode the Ovilus II will start in. The Ovilus II will say words from the Programmed dictionary and display the power level below the word.

To view words that have been spoken, hold down either ← or the →. It may take a few seconds then the screen will change to <---->. To see the last word spoken, press ← or → to scroll through the words that have been spoken.

Press the Mode switch to return to the **WORD** mode again.

- **Phonetic Mode:** The Ovilus II will speak using just phonemes, the sound fragments that make up words.
 - *In this mode, the screen is not active so the back light will turn off to save power.*
- **Reverse Phonetic Mode:** The Ovilus II will speak using just phonemes, the sound fragments that make up words. However the order in which they are produced is reversed from the order they were received.
 - *In this mode, the screen is not active so the back light will turn off to save power.*
- ***Temp F Mode:** Displays the temperature in Fahrenheit.
 - **Requires external temperature sensor.*
- **Volume Mode:** The user may use the ← or → buttons to increase or decrease the Volume. ← to decrease, → to increase.

Modes, continued

- **Contrast Mode:** The user may use the ← or → buttons to increase or decrease the contrast of the display. ← to decrease, → to increase.
- **B-Light (BackLight) Mode:** The user may use the ← or → buttons to increase or decrease the amount of time the display backlight is on. 0 = always on, anything more than 1 is the time, in minutes, it will remain on. ← to decrease, → to increase.
 - You may want to have the Ovilus II go dark after a short period of time to save power or to lower stray lighting.
- **Voice Mode:** The Ovilus II user may use the ← or → buttons to change the speaking voice of the Ovilus II. (8 “voices”)
- **Gain Mode:** User may use the ← or → to decrease or increase the sensitivity of the device. ← to decrease, → to increase.
- **Level Mode**
- ***EVP Mode:** Press ← to start a recording; Press → to play back.
 - **Requires external microphone & adapter.**
- **Flashlight:** The Ovilus II also has a built-in red flashlight. To turn on, press Mode and → at the same time. (It may take a few seconds.) To turn off, press Mode and ← at the same time.

Ovilus II Disclaimer

1. The Ovilus II is sold without any expectation. It is to be considered experimental.
2. The Ovilus II is sold as an **entertainment device only**. We make no claim to the validity of the data received by these devices.
3. We make no claim as to Spirit communications, Aliens, Ghosts or any other type of phenomena.
4. You agree not to expose children to this device, or any person who may be harmed or damaged by exposure to this device. Further, you must be over 18 and in sound mental condition.
5. As the owner of this device you are responsible for the devices use. Further, you are responsible for the safety of others who may come in contact with this device.
6. This device can generate disturbing text and speech; therefore it should not be used by children under the age of 18. Further, this device should not be used by anyone with a history of mental illness.
7. Why do we say *for entertainment use only*?
 - a. First and foremost, the devices are designed to aid in Paranormal Research, **not to be presented as evidence**.
 - b. This device can create speech and text, by method of taking energy levels in the environment and creating speech, nothing more! No algorithm is employed to produce text or speech in a specific pattern.
 - c. There's no person who can prove, to a certainty, what these messages are.
 - d. People need to take a rational, grounded approach to any device that creates speech or text. The power of suggestion is very strong!
 - e. Odds of this device saying a word that is contextually correct is 1 in 2048; in using phonetic speech, the odds are only 1 in 71.
 - f. A lot of claims have been made about devices such as this. Simple math will tell you the odds are much better than you think that it's just coincidence and nothing more.

The Use of this item in ANY media production is strictly prohibited without prior written approval from Digital Dowsing LLC.